

Method sheet: Packaging technology - Shrink Packer

Sheet no.: 050701 – 1.01 Date: June 2008

Machine: Shrink Packer

Criteria: Shape and position of the product group

### Contents:

1.	Definition: Machine and Criteria	. 2
0		
	Inspection	
2.1	Scope	. 2
	Apparatus	
2.3	Procedure	. 2
3.	Sampling	. 3
3.1	Calculation	. 3
3.2	Results and data sheets	. 4
3.2.1	Data sheet part (I/III)	. 4
3.2.2	Data sheet part (II/III)	. 5
3.2.3	Data sheet part (III/III)	. 6
	Evaluation and Documentation	
4.1	Evaluation	. 7
	Documentation	

<sup>&</sup>quot;The information and data provided in this document are non-binding outlines of a suggested best practice by the Association of the Beverage Machinery Industry (ABMI). It is your responsibility to assess whether it is feasible to use this information for your own undertakings. The ABMI will not be held liable for the use of the information or data provided in this document, or for the results of such use. Please see the Terms of Use on www.abm-industry.org for more details."



## Shape and position of the product group

### 1. Definition: Machine and Criteria

An important parameter of a shrink packer is the accuracy of the formed packages. If the used film fulfils the specifications prescribed by the manufacturer of the shrink packer, the produced packets have to be in a tolerance range as explained later.

For all actions the relevant safety instructions must be strictly adhered to.

### Further related documents:

free

### 2. Inspection

## 2.1 Scope

Detection of the deviation of shape and position of product groups of shirked packets to a set range by means of a ruler.

### 2.2 Apparatus

Ruler or sliding calliper with a precision better than  $\pm 0.01$  mm. A visual inspection of the used measurement devices by a person is necessary.

#### 2.3 Procedure

The shrink packer random samples have to be taken. The assessment threshold is the interface between the shrink tunnel exit and the downstream conveyor. The packets have to be checked accurately.

### The following parameters are recommended:

Variable	Α	=	Length of product group in MD
Variable	В	=	Width of product group in CD
Variable	C	=	Height of product group
Variable	D	=	Tolerance for "nested"
Variable	Ε	=	Tolerance for "angularity CD"
Variable	F	=	Tolerance for "angularity MD"
Variable	G	=	Tolerance for "centricity of the bull's eye"
Variable	Н	=	Tolerance for "centric of the film MD front and rear"
Variable	1	=	Tolerance for "centricity of the film MD top"






Fig. 01: Parameters concerning shape and position of a product group

## 3. Sampling

To check the accuracy of formed packages, samples are needed. Samples have to be taken after 15 minutes of production in standard operation and at nominal capacity.

Quantity of samples: 100 Packs.

The film should be cold and stable after the hot shrink tunnel.

## 3.1 Calculation

Free



3.2 Results and data	a sheets						
3.2.1 Data sheet part	(1 /111)						
Date:	Site:	Line:					
Product parameters:							
Product: Type of container (car	n, PET bottle, glass bottle e	e.g.)					

Fill in the measured result in [mm] for all variables shown in figure 1.

Number	А	В	С	D	Е	F	G	Н	
1									
2									
3								\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	
4									
5									
6									
7									
8									
9									
10									
11									
12									
13									
14									
15									
16									
17									
18									
19									
20									
21									
22									
23									
24									
25									



## 3.2.1 Data sheet part (II /III)

Number	Α	В	С	D	Е	F	G	Н	I
26									
27									
28									
29									
30									
31									
32									
33									
34									
35									
36									
37									
38									
39									
40									
41									
42									
43									
44									
45									
46									
47									
48									
49									
50									
51									
52									
53									
54 55									
55									
56									
57									
58									
59									
60									



## 3.2.3 Data sheet part (III /III)

Number	А	В	С	D	Е	F	G	Н	I
61									
62									
63									
64									
65									
66									
67									
68									
69									
70							\\.		
71									
72									
73									
74									
75									
76									
77									
78									
79									
80									
81									
82									
83									
84									
85									
86									
87									
88									
89									
90									
91									
92									
93									
94									
95									
96									
97									
98									
99									
100									



## 4. Evaluation and Documentation

4.1 Evaluation			
Variable A length min	=	mm	
Variable A length max	=	mm	
Variable A set	=	mm	
Variable A (length min) -	<u>≥</u>	Variable A <sub>(detected)</sub> ≤	Variable A <sub>(length max)</sub>
Variable B width min	=	mm	
Variable B width max	=	mm	
Variable B set	=	mm	
Variable B (width min) –	≥	Variable B <sub>(detected)</sub> ≤	Variable B (width max)
Variable C height min	=	mm	
Variable C height max	=	mm	
Variable C set			
Variable C (height min) –	≥	Variable C <sub>(detected)</sub> ≤	Variable C <sub>(height max)</sub>
Variable D tolerance mir	ı =	mm	
Variable D tolerance ma	x=	mm	
Variable D set			
Variable D (tolerance min) -	≥	Variable D <sub>(detected)</sub> ≤	Variable D <sub>(tolerance max</sub>
Variable E tolerance mir	ı =	mm	
Variable E tolerance ma	x=	mm	
Variable E set	=	mm	
Variable E (tolerance min) -	≥	Variable E <sub>(detected)</sub> ≤	Variable E <sub>(tolerance max</sub>
Variable F tolerance mir	ı =	mm	
Variable F tolerance ma	x=	mm	
Variable F set			
Variable F (tolerance min) _	<u> </u>	Variable F (detected) ≤	Variable F (tolerance max)



Variable G tolerance min =	_mm _mm	_Variable G <sub>(tolerance max)</sub>
Variable H tolerance min =	_mm	_Variable H <sub>(tolerance max)</sub>
Variable I tolerance min =  Variable I tolerance max =  Variable I set =  Variable I (tolerance min) ≥	mm mm	_Variable I <sub>(tolerance max)</sub>
4.2 Documentation		
The test is passed if ≥ 80 % of all package	es are in the tolerance range.	
Shape and position are o.k.  Shape and position are not o.k.		
Name and signature of inspector:		