

Method sheet: Capper – Opening torque of a flat cap Sheet no.: 050201 – 1.02 Date: February 2009

Machine:CapperCriteria:Opening torque of a flat cap

#### Contents:

1.	Definition: Machine and Criteria	2
2.	Inspection	2
2.1	Scope	2
2.2	Apparatus	2
2.3	Procedure	2
3.	Sampling	3
3.1	Calculation	3
3.2	Results and data sheets	3
3.2.1	Data sheet	3
4.	Evaluation and Documentation	4
4.1	Evaluation	. 4
4.2	Documentation	4

"The information and data provided in this document are non-binding outlines of a suggested best practice by the Association of the Beverage Machinery Industry (ABMI). It is your responsibility to assess whether it is feasible to use this information for your own undertakings. The ABMI will not be held liable for the use of the information or data provided in this document, or for the results of such use. Please see the Terms of Use on www.abm-industry.org for more details."



Association of the Beverage Machinery Industry

#### Opening torque of a flat cap

#### 1. Definition: Machine and Criterion

The torque is a relevant criterion of sealing machines. For all actions the relevant safety instructions must be strictly adhered to.

#### Further related documents:

- User manual of used measuring device
- 2. Inspection
- 2.1 Scope

Detection of the opening torque of closed bottles with a synthetic cap.

#### 2.2 Apparatus

Torque tester. The recommended accuracy of measurement instruments is 1 in-lb or 0.1 Nm. A visual inspection of the used measurement devices by a person is necessary.

#### 2.3 Procedure

Check the opening torque of the closed bottles with an adequate device and fill the results in the data sheet.



3. Sampling

To check torque, samples of closed packages are needed. Samples have to be taken after 15 minutes of production in standard operation and at nominal capacity.

Quantity of sample bottles: Quantity of 1 capper round.

Each of these caps has to be tested and the results have to be filled in on the following data sheet. Each different cap shape should have its own special opening aid.

#### 3.1 Calculation

Check if the measured result of torque is in the warranted range for the torque.

- 3.2 Results and data sheets
- 3.2.1 Data sheet

Number n:	x <sub>i</sub> [in-lbs]	Number n:	x <sub>i</sub> [in-lbs]	Fill in the results from measuring in inch-pounds [in-lbs].
1		21		Date:
2		22		
3		23		Site:
4		24		]
5		25		Product:
6		26		
7		27		Line:
8		28		
9		29		Type of capping:
10		30		
11		31		Conversion of units:
12		32		
13		33		• 1 Nm = 8851 in-lbs
14		34		• 1[Nm] • 8.851 = 1[in-lbs] and1[in-lbs] • 0,1129 = 1[Nm]
15		35		
16		36		
17		37		
18		38		
19		39		
20		40		]



4.	Evaluation and Documenta	ation							
4.1	Evaluation								
Torqu	ue measured (max):		- in lbs						
Torqu	ue measured (min):		_ in lbs						
Torqu	ue set:		_ in lbs						
Torqu	Je (Range (+)):		_ in lbs						
Torqu	Je (Range (-)):		_ in lbs						
Torque $(Range (-))$ in Ibs $\leq$ Torque $(measured)$ —		in lbs	6 ≤ .	Torque <sub>(F</sub>	(+)	) ———	_in lbs		
4.2	Documentation								

Torque accuracy is o.k. Torque accuracy is not o.k.

Name and signature of inspector: